

USB upgrade procedure: NTS01

This upgrade process applies to the following:

Clock Hardware Revision	Your Current Firmware Revision	Latest Firmware Revision
NTS01	D:xx.xx to D:xx.xx	D:09.010

WARNING: Please double check that your current firmware version matches the above table. If you are unsure please contact support@tekroninternational.com, we will get back to you within 1 working day.

Pre-update requirements

You will require the following:


- PC with a Windows operating system (2000, XP, Vista or Windows 7).
- Power supply rated at the recommended voltage for the unit.
- USB Cable
- NTS firmware D:xx.xx "NTS firmware 9010.exe".

Serial upgrade procedure

1. Disconnect power and then disconnect all outputs and the antenna from the unit.
2. Plug the unit into your PC using a USB cable.
3. Plug in the power.
4. Check that you are able to configure the unit via the USB configuration tool. Close the tool once verified.
5. Open "NTS firmware 9010.exe".



6. Click "Begin". The upgrade tool should start uploading the new firmware. If this does not happen, cycle the power on the unit again.



7. Click "Ok" when the upgrade has finished.

